






PROFESSIONAL TRUCK PARTS MANUFACTURING AND EXPORT

- ISUZU TRUCK
- EUROPEAN TRUCKS



For ISUZU NPR/FTR/FVR

ISUZU



Front Panel Assembly
(inner)
8-97585855-1



Rad Grille
(Chrome)L=133
1301112-PE25A1



Power Window Switch
8-98029234-0



Signal Lamp Assy LH
8-98155459-0



Side Mirror LH
8-98070493-0



Front Door Hinge
8-98038293-0



Tool Box (roof)LH
8204210-P301



Combination Switch
8-98073850-0



Relay (ECM) 5P
8-97833987-0



Relay (start) 4P
8-97264947-0



Door Handle
8-97301793-1



Tool Box (Roof) Bracket RH
8-97585576-3



Dashboard Side Panel
8-97406003-0



Front Bumper Bracket RH
2803040-P301



Front Side Panel
8-98028086-1



Spare Tire Rack
8-94341284-0



Best-selling
Products Worldwide

For ISUZU NPR/FTR/FVR

ISUZU



Fog Light LH
8-97378909-0



Fender LH
8-98022746-1



Tool Box
8-97405261-0



Able Gear Shaft (C)
8-97186398-0



Reverse Switch (gray)
1-82440083-2



Gear Shifter Dust Cover
(rubber)
1-79998913-0



Front Panel Assembly
8-98021859-0



Side Light LH
8-97410181-3



Power Window Switch
8-98316418-0



Clip
8-98021300-0



AC Switch
8-98067881-1



Relay 5P
8100340-FE64R



Crankshaft Bearing
M4547K1



Crankshaft
8-98029270-0



Brake Drum 6 Holes
(front and rear)
8-97188115-0



Pinion Gear Sets
1-41521035-2 1-41552020-0
1-41551024-0 8-97362599-0



For ISUZU NPR/FTR/FVR

ISUZU



Starter Assembly
8-98054984-1



Side Gear Thrust Washer
1-41562073-0



Camshaft Gear(Z=35)
8-98018935-3



Idle Gear (D)(Z=34)
8-97120005-0



Idle Gear (C)Z=41
8-97606929-0



Clutch Release Bearing
1-31310012-1



Exhaust Valve
8-97209876-3



Fan Belt 7PK1030
5-87610058-0



Camshaft
8-97262166-0



Valve Seal
8-97210702-0



Pinion Pilot Bearing(front)
8-97047296-0



Exhaust Manifold to Head Gasket
8-97146499-2



Common Rail Assy
8-98011888-2



Differential Oil Seal
1-09625484-0



Turbocharger Hose (Return)
8-97209950-0



Thermostat Housing
8-97329914-0



Best-selling
Products Worldwide

For ISUZU NPR/FTR/FVR

ISUZU



Flywheel Ring Z=138
1005022-P301



Oil Cooler Core
8-97334100-1



Differential Cage Bearing
9-00093130-0



Differential Side Gear Z=20
1-41561093-0



Clutch Master Cylinder Assembly
1607010-P401




Thermostat B (Mahle)
8-97300790-3



Thermostat A (Mahle)
8-97300787-3



Fuel Filter Assembly
8-98095980-0



Fuel Filter
1-87610093-4



EGR Valve 8P
8-97377509-8



Transmission Front Oil Seal
1-09625497-0



Fuel Injector Assembly
8-97609788-7



Glow Plug
8-94390777-4



Common Rail Pipe Pressure
Limiting Valve
8-98032549-0



Crankshaft Sensor 3p
8-97606943-0



Speed Sensor
8-97328058-2



For ISUZU NPR/FTR/FVR

ISUZU



Crankshaft Gear Z=42
8-94394342-4



Crankshaft Bearing
8-97372078-1



Neutral Switch
1-82440101-0



Idle Gear Shaft (B)
8-97350021-0



Cylinder Liner (Wanst)
8-98014046-0



Crankshaft Rear Oil Seal
8-98334339-0



Piston STD
8-98041062-0



Sensor 3P
(Camshaft)
8-98019024-0



Idle Gear (A) 72:60:30
8-97600586-1



Starter Assembly
8-98054984-0



Oil Pump (TBK)
8-98017585-1



Cylinder Head Gasket
8-98288503-0



Fuel Rail Pressure Sensor 3p
8-98119790-0



Lock ASM;STRG
8-97387036-1



EGR Cooler Assy
8-98212718-1



EGR Cooler Assy
8-98025248-0



For ISUZU NPR/FTR/FVR

ISUZU



EGR Valve 8P
8-98098257-5



Throttle Valve
8-98028416-7



Turbocharger
8-98027772-2



Fuel Injector Assembly
8-98160061-3



DPD sensor
8-98004329-0



DPD sensor
8-98004330-0



Clutch Pressure Plate D=325
5-87610104-0



Flywheel Assembly
(Z=138)
8-97326227-0



Upper Torsion Bar
8-97261872-0



Axle Shaft (Z=20)
8-97134439-0



Rear Brake Wheel Cylinder RH
(Rear)
8-97358879-0



Rear Brake Cylinder Assembly RH
(front)
8-97358881-0



Rear Brake Wheel Cylinder LH
8-97358878-0



Crankshaft Front Oil Seal
8-97329780-0



Blower Resistance
8-98077418-0



Bearing Nut Lock Washer
9-09653002-0



For ISUZU NPR/FTR/FVR

ISUZU



Wheel Nut (rear) LH
8-97081585-0



Wheel Nut (front) RH
3103042-P302



Radiator Heater Core
8-98047494-0



OIL PAN GASKET
8-97364386-0



Water Pump (TBK)
8-97363478-1



Wiper Motor
8-98029124-1



Rear Wheel Bearing (outer)
9-00093607-0



Rear wheel bearing (inner)
8-97122938-0



Rear Hub Bearing Nut
8-97137094-0



Condenser Assy
8-98025520-0



Brake Oil Tank
(power oil)
8-97306217-1



Air Conditioning Pulley
8-97161198-1



Air Conditioner Belt
8-98010841-0



Overhaul kit; supply pump
8-98145449-1



Overhaul kit; supply pump
8-98145501-1



Steering Wheel
8-97412556-0



For ISUZU NPR/FTR/FVR

ISUZU



Wheel Hub Bearing
3103031-P401



Rear Wheel Oil Seal (Inner)
8-97122937-0



Rear Wheel Oil Seal (Outer)
8-94336317-0



Leaf Spring Bushing
8-97034380-0



Leaf Spring Bushing
(iron)
8-97034380-0



Cab Mounting Rubber
(rear)
8-97086442-0



Manifold Sensor 5P
8-97601967-1



Radiator Assy
(without intercooler)
8-98046663-0



Fuse Box Cover (chassis)
8-98030767-1



Front Shock Absorber
8-98080129-1



Front Engine Foot Rubber LH
8-97122895-0



Air Filter Assembly(housing)
8-98050415-1



Starter Assembly
8-98009043-0



Clutch Booster
1-31800383-0



Crankshaft Metal Set STD
MP4000K



Nozzle Holder Sleeve
8-98018462-0



For ISUZU NPR/FTR/FVR

ISUZU



Synchronizer Slide Block
1-33269035-1



Jet; Oil
8-98173342-0



Gear Ring (5/6)
1-33265281-3



Slide Spring 5/6
1-09583228-1



Intake Valve (Mahle)
8-94395882-5



Fuel Injector Assembly
8-97609789-4



Sub Spring Rubber
8-94119958-1



Steering Oil Tank
8-97113159-0



Flywheel Assembly (Z=143)
8-98056355-2



Crankshaft Pulley
8-94395314-3



Clutch Disc D=350
1-87610140-0



Flywheel Assembly
8-94393849-1



Blister Fender
1-71268429-1



Ashtray (front door) LH
1-53497486-0



Power Window Switch RH
1-82380158-3



Fog Lamp Assembly LH
8-97353955-2



Best-selling
Products Worldwide

For ISUZU NPR/FTR/FVR

ISUZU



AC Control Assy
1-83543050-0



Flasher Relay 5P
1-83470060-0



Clutch Plate 380 * 10
1-87610119-0



Clutch Release Bearing
1-87610109-0



Clutch Master Cylinder
1607010-P401



Fuel Sedimenter
8-98162904-3



Clutch Master Cylinder
1-47500239-0



Final Pinion Oil Seal
1-09625322-0



Thermostat
8-98295921-1



Thermostat
8-97602048-2



Clutch Release Bearing
1-09820117-0



Water Pump (TBK)
1-87310835-0



Radiator Surge Tank
8-97205136-0



Exhaust-Brake Mag Valve
(Exhaust Braking)
1-82563602-0



Rear Wheel Bearing (inner)
1-09812233-0



Rear Wheel Bearing (Outer)
1-09812232-0



For ISUZU NPR/FTR/FVR

ISUZU



Air Relay Valve
1-48210278-5



Radiator Surge Tank
1-21480104-0



Air Compressor
8-98187304-2



Resistor; 2P
8-97357613-0



Differential Oil Seal (Middle Axle)
1-09625323-1



Head Asm; CYL; AIR CMPR
8-97614055-0



Propeller Shaft Journal Assy
1-37300102-0



Best-selling
Products Worldwide

For ISUZU NKR/QKR

ISUZU



Front Door Window Switch
8-97852116-0



Clip
8-94291927-0



Rear lamp assembly RH
8-94178618-0



Clip
8-97867240-0



Cable Clip
8-97211011-0



Cable Clip
8-97011448-0



Clip
8-97853168-0



Clip
(front fender lining)
8-97055001-0



Clutch Switch
8-97358248-0



Clip
8-97102415-0



Clip
8-94279974-1



Turn Signal Light LH
8-97365173-0



Front Headlight Assembly RH
8-97369570-0



Front Side Panel
(white)
8-97581608-0



Fuel Filter
8-98194119-0



Crankshaft Rear Oil
8-97071561-0



For ISUZU NKR/QKR

ISUZU



Piston Ring STD
8-94247867-2



Piston D=34 (dome)
8-97108621-0



Idle Gear (A) Z=31
8-94139759-0



Camshaft Gear Z=42
8-97079212-0



Valve Guide Seal
8-97120307-0



Idle Gear (B) Z=37
8-94139761-0



Crankshaft Gear Z=21
8-94139754-0



Clutch Disc 300 * 14
5-87610049-2



Throttle Assembly (EGR Valve)
1207010-PA11A



Clutch Pressure Plate D=300
5-87610079-0



Differential Bearing (front)
8-97107548-0



Thermostat (Mahle)
8-97361770-1



Oil Filter
5-87610009-0



Differential Bearing (rear)
5-09812062-0



Clutch Release Bearing
8-97316602-2



Clutch Kit D=250
5-87610207-0



Best-selling
Products Worldwide

For ISUZU NKR/QKR

ISUZU



Clutch Master Cylinder Assembly
8-98117644-1



Oil Filter
8-97329911-0



Air Filter Element
8-94156052-0



Oil Pump (TBK)
8-97308115-2



Throttle Assembly (DPF)
8-98040003-4



Clutch Release Bearing
5-87610110-0



Axle Shaft To Hub Stud
5-09300066-0



Axle Shaft Special Washer
9-09855207-0



SHOE: BRK, FRT (front and rear)
8-97035085-0



Front Shock Absorber
8-97107985-0



Hand Brake Disc Assembly
8-94378401-0



Final Drive Gear Set 7:43
8-97035455-0



Sub Fuel Tank Unit
8-94316190-0



Oil Pressure Switch (With Wire)
8-97072947-0



Gear Ring (1/2)
8-97074619-0



Rear Axle Hub Outer Bearing
9-00093082-0



For ISUZU NPR/FTR/FVR

ISUZU



Rear Axle Hub Inner Bearing
9-00093081-0



Blower Resistance 5P
8-97083135-0



Cushion Rubber
8-94118510-0



Rear Spring Shackle Bushing
8-94113323-0



Exhaust Brake Valve
8-97102372-0



Rear Shock Absorber
8-97160094-0



Wheel Nut (front) RH
3103042-861



Drag Link
8-97170158-0



For ISUZU GIGA

ISUZU



Switch Relay Valve (Air Pressure) 2.0 2P
8-98010856-1



Hazard Switch 8P
8-97386922-0



Lamp Asm; room
8-98013421-3



Front Door Power Window Regulator
8-98058429-0



Outside Mirror Cover
8-98031805-0



Outside Mirror Cover
RH(large)
8-98031802-2



Pressure Switch (air pressure)
0.3 2P
8-98010857-0



Pressure Switch (low pressure)
5.5 2P
8-97609249-0



Front headlight frame RH(chrome)
8-98273498-0



Oil Filter Element (Large)
8-97431167-0



Diesel Filter Element (Coarse)
8-98272997-0



Diesel Filter Element (Fine)
8-98273233-0



Oil Filter Element (Small)
8-97431166-0



Generator Assembly
8-97432970-0



Power Steering Oil Tank
8-94105282-1



Distributor Assembly
8-97040454-0



For ISUZU GIGA

ISUZU



Solenoid Valve
8-97641594-0



Trunnion Shaft Bushing
8-98081832-0



Exhaust Brake Mag Valve
(exhaust braking)
8-97431770-0



Fuse Box (chassis)
8-98034018-8



Under Mirror
8-97431222-0



Diesel Filter Element
8-98272997-0



Diesel Filter Element
1-87810976-0



Diesel Filter Element
8-98273233-0



Map Sensor (intake pressure)
8-98009418-0



Sensor (exhaust temperature) red
1205104-FE24H



Press Switch 3P
1-80220023-1



Press Sensor 3P
8-98020514-0



Under Mirror (ground mirror)
8-97431226-0



Generator Assembly
8-97433238-0



Engine Mounting Cushion Rubber
8-98055382-0



Fan Belt
1-87610101-0



For ISUZU GIGA

ISUZU



High Pressure Pump Valve Body
094040-0081



High Pressure Pump Valve
Body Assembly
094150-0318



Cover Gasket
1-09639034-2



Rear Lamp Assembly RH LED
4133020-D17YZ



Rear Shock Absorber
1-51630602-0



Rear Suspension Trunnion Shaft
1-51381022-2



Air tank Asm
1-51389058-0



Oil Pump
8-97431877-0



Oil Separator Filter Element
8-97625725-0



Starter Relay (flashing)
8-98005631-1



Starter Relay 5p
8-97173947-0



Cab Air Spring (Rear)
5002821-D17YZ



Cab Air Spring (Front)
1-52110142-3



Door Lock Relay 24V
8-98060789-0



Clutch Switch
8-97358248-0



Clutch Disc ISD212
8-97431272-0



For HINO 300/500

HINO



Corner Lamp LH/RH



Door Flasher Wide RH/LH



Front Bumper N/W



Front Grille N/W



Front Grille N/W



Headlamp LH/RH



Headlamp RH/LH



Headlamp RH/LH



Rear Pillar LH/RH



Step Panel RH/LH



Tail Lamp RH/LH



Truck Door Shell RH/LH



Clutch Disc
31250-2400



Clutch Disc
31250-2920



Clutch Disc
31250-4990



Clutch Disc
31250-6480



Best-selling
Products Worldwide

For HINO 300/500

HINO



Clutch Disc
31250-37320



Clutch Disc
HND008-ISD015



Clutch Disc
HND013



Clutch Disc
HND058U



Clutch Pressure Plate
HNC509



Clutch Pressure Plate
HNC517



Clutch Pressure Plate
ISC-549



Clutch Pressure Plate
HNC-532



Clutch Pressure Plate
HNC549



Flywheel
13450-1310



Flywheel
13450-1320



Flywheel
13450-2830



Flywheel
13450-2414



Water Pump
16100-2955



Water Pump
J05E



Water Pump
N04C-VB



Clutch Disc
HND013



Clutch Disc
MFD009



Clutch Disc
MFD013



Clutch Disc
MFD015



Clutch Disc
MFD037U



Clutch Pressure Plate
ME521106



Clutch Master Cylinder
MB295340



Clutch Master Cylinder
MC125304



Clutch Master Cylinder
ME600096



Clutch Master Cylinder
ME602994



Clutch Master Cylinder
MK429254



Clutch Master Cylinder
MK429255



Flywheel
ME431275



Flywheel
ME431260



Flywheel
ME093092



Flywheel
ME072584



For MITUBSHI



Best-selling
Products Worldwide

MITUBSHI



Flywheel
ME072248



Flywheel
ME012551



Flywheel
ME072102



Flywheel
ME012532



Brake Drum
MC865370



Brake Drum
MC807783



Ball Joint Tie Rod End
MC056808 MC056809



Ball Joint Tie Rod End
MC056810



Ball Joint Tie Rod End
MR420082



Ball Joint Tie Rod End
MR420083



Ball Joint Tie Rod End
MW033301



Ball Joint Tie Rod End
MW033302



Drag Link
MC063089



Drag Link
MC090448



Drag Link
MK382603



Fuso Clutch Kits



01

Engine Parts



Exhaust And Intake Valves
8-97209876-3
8-97131729-3




Cooling Fan Clutch
8-98019743-1



Full Set
5-87818556-2



Liner
8-98014046-B



Head Gasket
8-94145839-0



Turbocharger
8-97331185-0



Starter Assembly
8-98054984-0



Generator
8-98075026-2

02

Chassis Parts



COMLEN



Drag Link
8-98006794-A



Brake Pad Kits (Front)
8-98244794-0



Tie Rod End L R
1-43150802-0
1-43150801-0



Rear Wheel Oil Seal (Inner)
Front Hub Oil Seal
8-94248117-2 1-09425350-1



Air Flow Meter 5P
8-97601967-2



Flywheel Assembly (Z=138)
8-97326227-A



Steering Knuckle Repair Kit
5-87830978-2



Sub Tank Asm
1-21481143-1

03

Body Parts



Head Lamp
8-97369570-C



Front Turn Signal
8-97365172-C



Head Lamp
8-98241324-0



Front Turn Signal
8-97585173-1



Rad Grille
1301110-PE25A1



Rad Grille
(Chrome)



Chromed Parts



Chromed Parts



Clutch Disc
31250-E0780



Clutch Pressure Plate
31210-1064



Clutch Pressure Plate
TYC526



Clutch Disc
1-31240-980-0



Clutch Slave Cylinder
8-98089676-0



Clutch Master Cylinder
1-47500250-2



Clutch Booster slave cylinder
1-31800383-2



Clutch Release Bearing
1-09820117-0



Clutch Release Bearing
1-87610109-0



Clutch Release Bearing
8-97255313-0



Clutch Booster slave cylinder
1-31800383-2



Clutch Kits



Auto Parts for Japanese Truck